


**CSI-75K-T40001-E**

**CSI-80K-T40001-E**

**CSI-100K-T4001A-E**

**CSI-100K-T4001B-E**

**CSI-110K-T40001-E**



## **PV Inverter User Manual**

(Part No: 2809003300; Release Date: September, 2021)

## Contents

All Rights Reserve	1
About This Manual	1
Limitation of Liability	1
Target Group	1
Symbol Conventions	1
1 Safety	2
1.1 PV Panels	2
1.2 Utility Grid	2
1.3 Inverter	2
1.4 Skills of Qualified Personnel	3
2 Product Introduction	3
2.1 Intended Usage	3
2.2 Product Introduction	4
2.2.1 Appearance	4
2.2.2 LED Indicator Panel	6
2.3 Circuit Diagram	6
2.4 Function Description	7
3 Unpacking and Storage	8
3.1 Unpacking and Inspection	8
3.2 Identifying the Inverter	8
3.3 Scope of Delivery	9
3.4 Storage	9
4 Mechanical Mounting	10
4.1 Safety during Mounting	10
4.2 Location Requirements	10
4.2.1 Installation Environment Requirements	10
4.2.2 Carrier Requirements	11
4.2.3 Installation Angle Requirements	11
4.2.4 Installation Clearance Requirements	11
4.3 Moving the Inverter	12
4.3.1 Manual Transport	12
4.3.2 Hoisting Transport	12
4.4 Assembling the mounting-bracket	13
4.5 Standard C or U Steel Installation	14
4.6 Steel Frame Installation	14
4.7 Wall-Mounted Installation	15

4.8 Inverter Installation	15
5 Electrical Connection	16
5.1 Safety	16
5.2 Electrical Connection Overview	17
5.3 Connecting the PE Cable	18
5.3.1 Additional Grounding Requirements	18
5.3.2 Connection Procedure	18
5.4 Opening the Wiring Compartment	19
5.5 Communications Interface Description	20
5.6 RS485 Communication	20
5.6.1 Single-inverter communication system	20
5.6.2 Multi-inverter communication system	21
5.6.3 Connection Procedure (Terminal Block)	22
5.6.4 Connection Procedure (RJ45 network port)	23
5.7 Dry Contact Connection	23
5.8 Data Logger Connection	25
5.9 AC Cable Connection	25
5.9.1 AC Side Requirements	25
5.9.2 Connection Procedure	27
5.9.3 Aluminium Cable Requirement	28
5.10 Tracker System Power Supply Connection (Optional)	29
5.10 Closing the Wiring Compartment	30
5.11 DC Cable Connection	30
5.11.1 PV Input Configuration	31
5.11.2 Connection Procedure	31
5.11.3 Installing the PV Connectors	32
5.11.4 Wiring Procedure	32
6 Commissioning Inverter	33
6.1 Electrical Inspection	33
6.2 Commissioning Procedure	33
7 System Decommissioning	33
7.1 Disconnecting the Inverter	33
7.2 Dismantling the Inverter	33
7.3 Disposal of the Inverter	33
8 Daily Maintenance	34
9 Troubleshooting	38
9.1 Warning	38
9.2 Errors	38
ANNEX: Specification	42

## All Rights Reserve

This manual provides important safety information on relating to the installation, maintenance and usage of three phase PV inverters. Both users and professional installers must read these guidelines carefully and strictly follow these instructions. Failure to follow these instructions may result in death, serious injury or property damage. Only qualified professionals and service personnel can do the installation and operation (refer to 62109-1). Installers must inform end-users (consumers) about the aforesaid information accordingly.

This manual is only valid for the PV inverter types, CSI-75K-T40001-E, CSI-80K-T40001-E, CSI-100K-T40001-E, and CSI-110K-T40001-E produced by CSI Solar Co., Ltd.

## About This Manual

The information contained in this manual is subject to change by CSI Solar Co., Ltd. without prior notice. CSI Solar Co., Ltd. gives no warranty of any kind whatsoever, either explicitly or implicitly, with respect to the information contained herein.

In the event of any inconsistency among different language versions of this document, the English version shall prevail. Please refer to our product lists and documents published on our website at: <http://www.csisolar.com> as these lists are updated on a regular basis.

### Limitation of Liability

CSI Solar Co., Ltd. shall not be held responsible for damages of any kind, including-without limitation-bodily harm, injury or damage to property, in connection with handling PV inverters, system installation, or compliance or non-compliance with the instructions set forth in this manual.

### Target Group

This document is intended for installers and users.

### Symbol Conventions

The Important instructions contained in this manual should be followed during installation, operation and maintenance of the inverter. They will be highlighted by the following symbols.

Symbol	Description
 DANGER	Indicates a hazard with a high level of risk that, if not avoided, will result in death or serious injury.
 WARNING	Indicates a hazard with a medium level of risk that, if not avoided, could result in death or serious injury.
 CAUTION	Indicates a hazard with a low level of risk that, if not avoided, could result in minor or moderate injury.
 NOTICE	Indicates a situation that, if not avoided, could result in equipment or property damage.
 Information	Indicates additional information, emphasized contents or tips that may be helpful, e.g. to help you solve problems or save time.

# 1 Safety

The inverter has been designed and tested strictly according to international safety regulations. Read all safety instructions carefully prior to any work and observe them at all times when working on or with the inverter.

Incorrect operation or work may cause:

- Injury or death to the operator or a third party; or
- Damage to the inverter and other property safety of the operator or a third party. All detailed work-related safety warning and notes will be specified at critical points in this manual.

Notice:

The safety instructions in this manual cannot cover all the precautions that should be followed. Perform operations considering actual onsite conditions.

CSI Solar shall not be held liable for any damage caused by violation of the safety instructions in this manual.

 <b>DANGER</b>
<p>PV strings will produce electrical power when exposed to sunlight and can cause a lethal voltage and an electric shock.</p> <ul style="list-style-type: none"> <li>- Always keep in mind that the inverter is dual power supplied. Electrical operators must wear proper personal protective equipment: helmet, insulated footwear, glove, etc.</li> <li>- Before touching the DC cables, operator must use a measuring device to ensure that the cable is voltage - free.</li> <li>- Follow all warnings on the PV strings and in its manual.</li> </ul>

## 1.1 Utility Grid

Please follow the regulations related to the utility grid.

 <b>NOTICE</b>
<p>All electrical connections must be in accordance with local and national standards. Only with the permission of the utility grid, the inverter can be connected to the utility grid.</p>

## 1.2 Inverter

 <b>DANGER</b>
<p>Danger to life from electric shocks due to live voltage</p> <ul style="list-style-type: none"> <li>- Do not open the enclosure at any time. Unauthorized opening will void guarantee and warranty claims and in most cases terminate the operating license.</li> </ul>

 <b>WARNING</b>
<p>Risk of inverter damage or personal injury</p> <ul style="list-style-type: none"> <li>- Do not pull out the PV connectors when the inverter is running.</li> <li>- Wait at least 5 minutes for the internal capacitors to discharge. Ensure that there is no voltage or current before pulling any connector.</li> </ul>

 <b>CAUTION</b>
<p>Risk of burns due to hot components! Do not touch any hot parts (such as heat sink) during operation. Only the DC switch can safely be touched at any time.</p>

 **NOTICE**


Only qualified personnel can perform the country setting.

- Unauthorized alteration of the country setting may cause a breach of the type-certificate marking.

By touching the electronic components, you may damage the inverter. For inverter handling, be sure to:

- avoid any unnecessary touching;and,
- wear a grounding wristband before touching any connectors.
- Persons with limited mobility or mentally retarded are not allowed to operate the inverters.

**Warning Label**

Symbol	Description
	Hot surfaces! Risk of burns due to hot components!
	Disconnect the inverter from all the external power sources before service!
	Danger to life due to high voltage!
	Time need to discharge stored energy in the capacitors.
	Grounding
	Direct Current (D C)
	Alternating Current(A C)

**1.3 Skills of Qualified Personnel**

All installations should be performed by qualified personnel. They should have:

- Training in the installation and commissioning of the electrical system, as well as the dealing with hazards.
- Knowledge of the manual and other related documents.
- Knowledge of the local regulations and directives.


**2 Product Introduction****2.1 Intended Usage**

The inverter is a transformerless three-phase PV grid-connected inverter, is an integral component in the PV power system.

This document involves the following product models:

CSI-75K-T40001-E, CSI-80K-T40001-E, CSI-100K-T4001A-E, CSI-100K-T4001B-E and CSI-110K-T40001-E.


The inverter is designed to convert the direct current power generated from the PV modules into grid-compatible AC current and feeds the AC current to the utility grid. The intended usage of the inverter is illustrated in figure as bellow, inverter application in PV power system.



A) PV string; B) Inverter; C) AC distribution box/cabinet; D) Transformer station; E) Utility grid  
 Inverter application in PV power system


 **WARNING**

Inverter cannot connect the PV strings whose positive and negative terminals need to be grounded.  
 Do not connect any local load between the inverter and the AC circuit breaker.




## 2.2 Product Introduction


### 2.2.1 Appearance and dimension



CSI-100K-T4001B-E  
CSI-110K-T40001-E



CSI-75K-T40001-E  
CSI-80K-T40001-E  
CSI-100K-T4001A-E



Note: the image shown here is for reference only. The actual product you receive may differ.

- 1.LED indicator Panel
- 2.Side handles and mounting ears
- 3.Bottom handles
- 4.M12 holes for lifting eyes or hand shanks
- 5.M12 holes for hand shanks
- 6.Additational grounding points
- 7.Rating label
- 8.Warning label
- 9.The cover of outer fan module
- 10.The cover of interior fan module
- 11.PV input connectors
- 12.DC disconnect switch
- 13.Cable gland for AC output
- 14.Cable gland for interior grounding
- 15.Cable gland for communication
- 16.Communication connector for data logger
- 17.Breather valve

### 2.2.2 LED Indicator Panel

As an HMI, the LED indicator panel on the front of the inverter can indicate the present working state of the inverter.



LED indicator	LED state		Definition
 PV connection indicator	Not in maintenance status	Steady green	At least one PV string is properly connected, and the DC input voltage of the corresponding MPPT circuit is at least 200V.
		Off	The solar inverter disconnects from all PV strings, or the DC input voltage of all MPPT circuits is less than 200V.
	In maintenance status	Blinking green	DSPM in copying or updating
		Steady green	DSPM copy or update succeeds.
 Grid connection indicator	Not in maintenance status	Steady green	The solar inverter is in grid-tied mode.
		Blinking green fast	The solar inverter is in self-test mode.
		Blinking green slowly	The solar inverter is in wait mode.
		Off	The solar inverter is not in grid-tied mode.
	In maintenance status	Blinking green	ARMS in copying or updating
		Steady green	ARMS copy or update succeeds.
		Off	ARMS copy or update fails.
 Communications/Maintenance indicator	Not in maintenance status	Blinking green	The solar inverter receives communication data normally
		Off	The solar inverter has not receives communication data for 10 seconds.
	In maintenance status	Steady green	The solar inverter is in maintenance status
 Alarm indicator	Not in maintenance status	Steady green	A major alarm is generated.
		Blinking green fast	A minor alarm is generated.
		Blinking green slowly	A warning alarm is generated.
		Off	No alarm
	In maintenance status	Blinking green slowly	The solar inverter is in update maintenance mode.
		Off	The PID function of solar inverter is on work.




Turn the DC switches to the ON position before restarting the inverter.

### 2.3 Circuit Diagram

The MPPT is utilized for DC input to ensure the maximum power from the PV array at different PV input conditions. The inversion circuit converts the DC power into AC power and feeds the AC power into the utility grid through the AC terminal. The protection circuit is equipped to ensure the safe operation of the device and personal safety.

The following figure shows the main circuit of the inverter.



### 2.4 Function Description

The inverter is equipped with the following functions:

1) Conversion function

The inverter converts the DC current into grid-compatible AC current and feeds the AC current into the grid.

2) Data storage

The inverter logs running information, error records, etc.

3) Parameter configuration

The inverter provides various settable parameters. Users can set parameters via the App to meet the requirements and optimize the performance.

4) Communication interface

The inverter is designed with standard RS485 communication interfaces.

The standard RS485 communication interfaces are used to establish communication connection with monitoring devices and upload monitoring data by using communication cables.


After communication connection is established, users can view inverter information or set inverter parameters through the iSolarCloud.

5) Protection Function

The protective functions are integrated in the inverter, including anti-island protection, LVRT/ZVRT, DC reversed polarity protection, AC short circuit protection, leakage current protection, DC overvoltage/overcurrent protection, etc.

6) PID function

After the PID function is enabled, the voltage to ground of all PV modules is greater than 0, that is, the PV module-to-ground voltage is a positive value.



**NOTICE**

- Before enabling the PID recovery function, make sure the voltage polarity of the PV modules to ground meets requirement. If there are any questions, contact the PV module manufacturer or read its corresponding user manual.
- If the voltage scheme for the PID protection/recovery function does not meet the requirement of corresponding PV modules, the PID function will not work as expected or even damage the PV modules.

- Anti-PID function

When the inverter is running, the PID function module rises the potential between the negative pole of the PV array and the ground to a positive value, to suppress the PID effect.



Make sure the inverter is applied to an IT system before enabling the anti-PID function.

- PID recovery function

When the inverter is not running, the PID module will apply inverse voltage to PV modules, to restore the degraded modules.



- If the PID recovery function is enabled, it only works at night.
- After the PID recovery function is enabled, the voltage of the PV string to ground is 500Vdc by default, and the default value can be modified through the App.

## 3 Unpacking and Storage

### 3.1 Unpacking and Inspection

Before unpacking the inverter, check the package appearance thoroughly, such as for holes and cracks, and check the inverter model accordingly. If you discover any damage to the packaging which indicates the inverter may have been damaged, or the inverter model is not the one you requested, do not unpack the product and contact your dealer immediately.

After opening the package, check all of the accessories carefully in the carton. If any damage is found or any component is missing, contact your local installer.

### 3.2 Identifying the Inverter


The nameplate provides a unique identification of the inverter (Product type, device -specific characteristics, certificates and approvals).

The nameplate is on the left side of the enclosure.

		<p><b>WARNING:</b> Electric Shock Hazards! DC conductors of the photovoltaic system are ungrounded and may carry lethal voltage.</p> <p><b>WARNING:</b> Electric Shock Hazards! DC conductors of the photovoltaic system are generally ungrounded but will be intermittently grounded without indication when the inverter measures the PV carry insulation resistance.</p> <hr/> <p><b>CAUTION:</b> Risk of Electric Shock! Do not remove the cover.No user serviceable components inside.Maintained by qualified personnel only.</p> <p><b>CAUTION:</b> Risk of Electric Shock! (a)Both AC and DC wiring terminals are inside the device.Disconnect each circuit before maintenance. (b)Once exposed to sunlight,the PV array will generate voltage.</p> <hr/> <p> <b>CAUTION:</b> Risk of electric shock from energy stored in the capacitor. Do not recover until 5 minutes later after disconnecting all sources of supply.</p> <hr/> <p> <b>CAUTION:</b> Beware of Burning! Hot surface.Do not touch the running device.</p> <hr/> <p> <b>CAUTION:</b> Read the manual before operation and maintenance.</p>
<p>Product Name: Grid-connected PV Inverter Model Number: CSI-110K-T40001-E Vmax. PV(absolute max.): DC 1100V MPPT Voltage Range: DC 200-1000V Max. Input Current: DC 9 x 30A Isc PV(absolute max.): DC 9 x 40A Rated Output Power: 110kW Max. Output apparent Power: 110kVA AC Nominal Voltage: 3/N/PE ~ 220/380V 3/N/PE ~ 230/400V 3 ~ 380/400V AC Nominal Frequency: 50/60Hz Max. Output Current: AC 167A Power Factor: 0.8 leading...0.8 lagging Protection Class: I Overvoltage Class: II(DC), III(AC) Degree of Protection: IP66 Operating Temperature Range: -30°C...+60°C Made in China</p>	<p> </p> <p style="text-align: center;">(SN LABEL)</p> <p style="text-align: right;">6243003600(IEC)</p>	

Inverter Nameplate (for reference)

### 3.3 Scope of Delivery



Number of PV connectors, 18 pcs for the type of 9MPPTs, and 12 pcs for the type of 6MPPTs.

The actual configuration in order to prevail in kind.

### 3.4 Storage

The following requirements should be met when the inverters need to be stored:


Storage temperature:  $-40^{\circ}\text{C} \sim +70^{\circ}\text{C}$ .

Storage humidity: 0% ~ 100%RH (Non-Condensing).

The warehouse should be clean, well-ventilated, and non-corrosive gas (corrosive or flammable gases), meanwhile it should be accessible all the time.

No smoking, no illegal use of electricity and fire.

When storing inverters, do not stack more than the allowed layers to avoid damage, which number marked on the product packaging.



Do not tilt the package or place it upside down.

Regular inspection is required during the storage.

If the inverter has been stored more than half a year, it must be checked and tested by professionals before put into use.

## 4 Mechanical Mounting

### 4.1 Safety during Mounting



#### DANGER

Make sure there is no electrical connection before installation.

In order to avoid electric shock or other injury, be sure there is no electricity or plumbing installations before drilling holes.



#### CAUTION

Risk of injury due to improper handling

- Always follow the instructions when moving and positioning the inverter.
- Improper operation may cause injuries, serious wounds, or bruise.

System performance loss due to poor ventilation!

- Keep the heat sinks uncovered to ensure heat dissipation performance.

### 4.2 Location Requirements

Select an optimal mounting location for safe operation, long service life, and outstanding performance.

- The inverter with IP 66 can be installed both indoors and outdoors.
- Install the inverter in a place convenient for electrical connection, operation, and maintenance.




#### 4.2.1 Installation Environment Requirements

- 1) Do not install the inverter on the structures constructed of flammable, thermolabile or explosive materials.
- 2) Ensure the inverter is out of children's reach.
- 3) The ambient temperature should be between  $-25^{\circ}\text{C}$  to  $60^{\circ}\text{C}$ .
- 4) The humidity of the installation location should be below 100% without condensation.
- 5) Do not install the inverter outdoors in salt, sulfur or other corrosive areas.

The inverter would be corroded in salt (i.e. marine environments) area, and the corrosion may cause fire. In salt area refers to the region within 500 meters from the coast.

Please consult the CSI Solar Co., Ltd. technical support department on the use of inverters in special climates (i.e. salt, sulfur, or ammonia areas) which may affect the product warranty.

- 6) Prevent the inverter from direct exposure to sun, rain and snow.
- 7) The inverter should be well ventilated. Ensure air circulation
- 8) Never install the inverter in living areas. The inverter will generate noise during operation, affecting daily life.
- 9) Install at an appropriate height for ease of viewing LED indicators and operating switches
- 10) Do not install in small closed cabinet where air cannot circulate freely.



### 4.2.2 Carrier Requirements


The installation carrier should meet the following requirements:

Made of non-inflammable materials;

Max. load bearing capacity  $\geq 4$  times of inverter weight.

### 4.2.3 Installation Angle Requirements


Inverter vertically or at a minimum back tilt of  $10^\circ$ . Forward installation or upside down installation is prohibited.




### 4.2.4 Installation Clearance Requirements

1) Reserve enough clearance around the inverter to ensure sufficient space for heat dissipation. (The fans are maintained on the left side of the inverter, and a larger clearance is required.)


In case the distance is less than 800mm, move the inverter from the mounting-bracket or wall before maintaining fans.



2) In case of multiple inverters, reserve specific clearance between the inverters.



3) In case of back-to-back installation, reserve specific clearance between the two inverters.




### 4.3 Moving the Inverter

Move the inverter to the specified position before installation. The inverter can be moved manually or via a hoist.

#### 4.3.1 Manual Transport

Step 1 Install four screw-in hand shanks into the corresponding M12 holes, which holes in the handles at side and bottom of the inverter.



Step 2 Lift and move the inverter to the destination by using the side and bottom handles as well as the four installed hand shanks.

Step 3 Remove the four hand shanks .

#### CAUTION

Inappropriate moving operation may cause personal injury!

It is recommended that at least four installers carry the inverter together and wear protective equipment such as smash - proof shoes and gloves.

Always beware of the gravity center of the inverter and avoid tipping.

#### NOTICE

The ground surface on which the inverter is to be placed should be covered with a sponge pad, foam cushion or the like to prevent the inverter bottom from scratches.


#### 4.3.2 Hoisting Transport

Step 1 Install two M12 lifting eye nuts into the corresponding M12 holes at side handles of the inverter.

Step 2 Lead the sling through the two lifting eye nuts and fasten the tie-down strap.

Step 3 Hoist the inverter, and stop to check for safety when the inverter is 100mm above the ground. Continue hoisting the device to the destination after ensuring the safety.

Step 4 Remove the two lifting eye nuts.



**CAUTION**


Keep the inverter balanced throughout the hoisting process and avoid collisions with walls or other objects. Stop hoisting in the event of severe weather, such as heavy rain, thick fog, or strong wind.




The lifting rings and the sling are not within the delivery scope.

**4.4 Assembling the mounting-bracket**

Dimensions of the assembled mounting-bracket are as follows:



Assemble the mounting-bracket by using the connecting bar.




### 4.5 Standard C or U Steel Installation

Mounting Steps:

Step 1 Localize the hole positions in C or U-section steel to install mounting bracket.


Step 2 Secure the mounting bracket with M10 bolts and nuts.




### 4.6 Steel Frame Installation

Mounting Steps:

Step 1 Level the assembled mounting-bracket by using a level, and mark the positions for drilling holes on the steel frame. Drill the holes by using a hammer drill.



Step 2 Secure the mounting-bracket with M10 bolts and nuts.




## 4.7 Wall-Mounted Installation

### Mounting Steps


Step 1 Level the assembled mounting-bracket by using a level, and mark the positions for drilling holes on the installation site.

Step 2 Insert the expansion bolts into the holes and secure them with a rubber hammer. Fasten the nut with a wrench to expand the bolt. Remove the nut, spring washer, and flat washer, and store them properly.



Step 3 Fix the mounting-bracket with the expansion bolts.

(Note: No expansion bolt is supplied.)




Note: No expansion bolt is supplied.

## 4.8 Inverter Installation


Step 1 Take out the inverter from the packing carton.

Step 2 Hoist the inverter to the installation position when necessary (refer to "4.3.2 Hoisting Transport"). If the installation position is not high enough, skip performing this step.

Step 3 Hang the inverter to the mounting-bracket and ensure that the mounting ears perfectly engage with the mounting-bracket.



Step 4 Fix the inverter with screws M6x30.



## 5 Electrical Connection

### 5.1 Safety

Prior to any electrical connections, keep in mind that the inverter has dual power supplies.

It is mandatory for the qualified personnel to wear personal protective equipments (PPE) during the electrical work.



#### **DANGER**

Danger to life due to a high voltage inside the inverter!

- The PV string will generate lethal high voltage when exposed to sunlight.
- Before starting electrical connections, disconnect the DC and AC circuit. breakers and prevent them from inadvertent reconnection.
- Ensure that all cables are voltage free before performing cable connection.

**WARNING**


Any improper operations during cable connection can cause device damage or personal injury.  
 Only qualified personnel can perform cable connection.  
 All cables must be undamaged, firmly attached, properly insulated and adequately dimensioned.

**NOTICE**

Comply with the safety instructions related to the PV strings and the regulations related to the utility grid.  
 - All electrical connections must be in accordance with local and national standards.  
 - Only with the permission of the utility grid, the inverter can be connected to the utility grid.

**5.2 Electrical Connection Overview**

Electrical connection in the PV system includes additional grounding connection, AC connection, and PV string connection.



A) PV string; B) Inverter; C) AC distribution box/cabinet; D) Utility grid; E) Monitoring device

Table 5-1 Recommended Cables

Cable Name	Cable Type	Conductor Cross-Sectional Area	Outer Diameter
DC cable	PV cable, complying with 1500V standard	4~6mm <sup>2</sup>	6~9mm
Additional Grounding cable	Outdoor single core copper conductor cable	The same as that of the PE wire in the AC cable	N/A
AC cable	Four/Five-core outdoor copper or aluminum cables*	1) 4 or 5 x 70~185 mm <sup>2</sup> 2) 3 x 240+1 x 120mm <sup>2</sup> PE wire: refer to "table 5-2 PE wire requirements"	36~57mm
Communication cable	Shielded twisted pair (terminal block) CAT-5 Ethernet cable (RJ45)	0.1~0.5 mm <sup>2</sup> N/A	4~15mm

\* A copper to aluminum adapter terminal is required when an aluminum cable is used.

For details, refer to "5.9.3 Aluminium Cable Requirements".

Table 5-2 PE wire requirements

Phase wire cross section S	PE wire cross section	Note
S > 35 mm <sup>2</sup>	S/2	The specifications are valid only when the phase wire and PE wire use the same material. If otherwise, ensure that the cross section of PE wire produces a conductance equivalent to that of the wire specified in the table.

Table 5-3 Power cable for tracking system

Cable	Cable Type	Conductor Cross-Sectional Area	Outer Diameter	Voltage level
Power cable for tracking system	Outdoor copper conductor cable	2 or 3 x 4~10mm <sup>2</sup> *	9~18mm	Consistent with selected AC cable

### 5.3 Connecting the PE Cable

**WARNING**

Since the inverter is a transformerless inverter, neither the negative pole nor the positive pole of the PV string can be grounded. Otherwise, the inverter will not operate normally.

Connect the additional grounding terminal to the protective grounding point before AC cable connection, PV cable connection, and communication cable connection.

The ground connection of this additional grounding terminal cannot replace the connection of the PE terminal of the AC cable. Make sure these terminals are both grounded reliably.


#### 5.3.1 Additional Grounding Requirements

All non-current carrying metal parts and device enclosures in the PV power system should be grounded, for example, brackets of PV modules and inverter enclosure. When there is only one inverter in the PV system, connect the additional grounding cable to a nearby grounding point.


When there are multiple inverters in the PV system, connect grounding points of all inverters and the PV array frames to the equipotential cable (according to the onsite conditions) to implement an equipotential connection.

#### 5.3.2 Connection Procedure

Step 1 Prepare the cable and OT/DT/DTM terminal.



Step 2 Remove the screw on the grounding terminal and fasten the cable with a screwdriver.




Step 3 Apply paint to the grounding terminal to ensure corrosion resistance.

	<p>The grounding screws have been anchored to the side of the inverter before delivery, and do not need to be prepared.</p> <p>There are two grounding terminals. Use at least one of them to ground the inverter.</p>
--	--


### 5.4 Opening the Wiring Compartment

Step 1 Loosen four screws on the front cover of the wiring compartment with screwdriver T30.

Step 2 Open the wiring compartment.




Step 3 Loosen two screws on the communication board, and remove the protection cover.



	<p>Close the wiring compartment in reverse order after completing wiring operations.</p>
--	--

### 5.5 Communications Interface Description

The following figure shows the position of the communication wiring board in the inverter as well as the terminals equipped for the wiring board.




### 5.6 RS485 Communication

The inverter is equipped with four groups of RS485 communication port for external communication connection, which are RS485\_1, RS485\_2, RS485\_3, and RS485\_4.

The terminal block interface and RJ45 interface have the same function with only wiring manner different. Select either interface for cable connection.

#### 5.6.1 Single-inverter communication system


In case of a single inverter, select either terminal block interface (RS 485-1, and RS 485-3) or RJ45 interface(C1~C8) to connect.




5.6.2 Multi-inverter communication system

In case of multiple inverters, select either terminal block interface or RJ45 interface to connect.

1) All the inverters are connected via terminal block interface (RS485 cables) in the daisy chain.




2) All the inverters are connected via RJ45 interface (internet cable) in the daisy chain.



3) More than 15 pcs inverters communication.

All the inverter are connected via terminal block interface (RS485 cables) in the daisy chain.

When more than 15 inverters are connected on the same daisy chain, the inverters on two ends of the chain should be equipped with terminal resistors of 120Ω to ensure communication quality by configuring the dip switch (SW2), and the shielding layer of the communication cable should be single-point grounded.



 The length of the RS485 cable should be no longer than 1,200m.

### 5.6.3 Connection Procedure (Terminal Block)

 RS485 communication cables should be shielded twisted pair cables or shielded twisted pair Ethernet cables.


Step 1 Strip the protection layer and insulation layer by appropriate length.

Step 2 Loosen the swivel nut of the communication terminal and select an appropriate seal according to cable outer diameter. Lead the cable through the swivel nut and seal successively.

Step 3 Secure the cable to the terminal base.

Step 4 Insert the terminal base into the corresponding terminal.

Step 5 Pull the cable gently to make sure it is secured, tighten the swivel nut clockwise.




### 5.6.4 Connection Procedure (RJ45 network port)

Step 1 Loosen the swivel nut of the communication terminal and select an appropriate seal according to cable outer diameter. Lead the cable through the swivel nut and seal successively.

Step 2 Strip the insulation layer of the Ethernet cable with a wire stripper, and insert the signal wires to the RJ45 connector. Crimp the RJ45 connector with a crimping tool.

Step 3 Insert the RJ45 connector to the RJ45 jack.

Step 4 Pull the cable gently to make sure it is secured, tighten the swivel nut clockwise.



## 5.7 Dry Contact Connection


### Dry Contact Function

Connection method of the dry contacts is similar to that of the RS485 terminal block.


DO terminal (fault output dry contact): the relay can be set to fault alarm output, and user can configure it to be a normal open contact (COM&NO).

The relay will trip to closed when a fault occurs. Use LED indicators or other equipment to indicate whether the inverter is in the faulty state.

- 1) Free of fault, relay dose not trip. Circuit is disconnected and LED indicator is off;
- 2) Fault occurs, relay trips. Circuit is connected and LED indicator gets on.




DI terminal (emergency stop dry contact): the dry contact can be configured to be an emergency stop contact. When the DI contact and +5V contact are shorted by external controlled switch, the inverter will immediately stop




 The dry contacts only support passive switch signal input.

Dry contacts connection procedure:




Reinstall the protection plate of communication board.



### 5.8 Data Logger Connection

Connect the Data Logger to the communication accessory port.

After successful connection, information such as power generation and running state of the inverter can be viewed via the APP on the phone.



### 5.9 AC Cable Connection

#### 5.9.1 AC Side Requirements

Before connecting the inverter to the grid, ensure the grid voltage and frequency comply with requirements, for which, refer to Specification. Otherwise, contact the electric power company for help.

	<p>Connect the inverter to the grid only after getting an approval from the local electric power company.</p>
--	---

### AC Circuit Breaker

An independent four-pole circuit breaker is installed on the output side of the inverter to ensure safe disconnection from the grid.

Inverter	Recommended rated voltage	Recommended rated current
CSI-75K-T40001	400V	150A
CSI-80K-T40001	400V	150A
CSI-100K-T4001A	400V	200A
CSI-100K-T4001B	400V	200A
CSI-110K-T40001	400V	200A

If multiple inverters need to share a circuit breaker, the circuit breaker should be selected according to the capacity.

 <b>NOTICE</b>
Never connect a load between the inverter and the circuit breaker.

### Multiple Inverters in parallel Connection

If multiple inverters are connected in parallel to the grid, ensure that the total number of parallel inverters does not exceed 25. Otherwise, please contact CSI Solar for technical scheme.

### MV transformer

The MV transformer used together with the inverter should meet the following requirements:

- 1) The transformer may be a distribution transformer, and it must be designed for the typical cyclical loads of a PV system (load in the day and no load at night).
- 2) The transformer may be of the liquid-immersed type or dry type, and shield winding is not necessary.
- 3) The line-to-line voltage on the LV side of the transformer should endure the output voltage of inverter. When the transformer is connected to the IT grid, to-ground withstanding voltage of the LV winding of the transformer, the AC cables, and the secondary equipment (including the relay protection device, detection & measuring device, and other related auxiliary devices) should not be lower than 1,100V.
- 4) The line-to-line voltage on the HV side of transformer should comply with local power grid voltage.
- 5) A transformer with a tap changer on the HV side is recommended in order to keep consistent with the grid voltage.
- 6) At an ambient temperature of 45°C, the transformer can run in 1.1 times of load for long time.
- 7) Transformer with a short-circuit impedance 6% (permissible tolerance: ±10%) is recommended.
- 8) The voltage drop of system cable is no more than 3%.
- 9) The DC component that the transformer can withstand is 1% of the fundamental current at rated power.
- 10) For thermal rating, the load curve of the transformer and environment conditions should be taken into account.
- 11) The apparent power of the inverter should never exceed the power of the transformer. The maximum AC current of all inverters connected in parallel must be taken into account. If more than 25 inverters are connected to the grid, contact CSI Solar.
- 12) The transformer must be protected against overloading and short circuit.
- 13) The transformer is an important part of grid-connected PV generation system. The fault tolerance capacity of the transformer should be taken into account at all times.


The fault include: system short circuit, grounding fault, voltage drop, etc.

14) Take ambient temperature, relative humidity, altitude, air quality, and other environmental conditions into account when selecting and installing the transformer.

15) When the anti-PID function is enabled, observe the following items:

- If the LV side winding is in Y shape, neutral point grounding is prohibited.
- Surge protective devices (SPD) for the AC combiner box and on the LV side of the transformer are recommended to be connected in the "3 +1" manner, as shown in the figure below. The Min. continuous operating voltages of M1-M4 are 460VAC.

- The LV side winding of the transformer, AC cables, and secondary devices (- including protective relay, detection and measurement instruments, and related auxiliary devices) must withstand the voltage to ground of at least 1,000V.




**NOTICE**

Ensure that the selected terminal can directly contact with the copper bar.  
 If there are any problems, contact the manufacturer of terminal.  
 Direct contact between the copper bar and the aluminium cable will cause electrochemical corrosion and impair the reliability of electrical connection.

5.9.2 Connection Procedure

Step 1 Open the wiring compartment.


Step 2 Pull out four plastic rivets on the protection plate, then remove the protection plate.



Step 3 Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.


Step 4 Loosen the swivel nut of the AC waterproof connector and select a seal rings according to the cable outer diameter. Lead the cable through the swivel nut, seal rings, and wiring terminal successively.

Step 5 Strip the protection layer and insulation layer by specific length, as described in the figure below.




Step 6 If wiring of tracking system power cable is required, refer to "5.10 Wiring of Tracking System Power Cable (Optional)". Otherwise, skip performing this step.

Step 7 Make the cable and crimp OT/DT/DTM terminal.




Step 8 Secure the wires to corresponding terminals.

Step 9 Gently pull the cable backwards to ensure firm connection, and fasten the swivel nut clockwise.




### 5.9.3 Aluminium Cable Requirement


If an aluminium cable is selected, use a copper to aluminium adapter terminal to avoid direct contact between the copper bar and the aluminium cable.




### 5.10 Tracker System Power Supply Connection (Optional)




Strip the protection layer and insulation layer by specific length, as described in the figure below.



Make the cable and crimp OT/DT/DTM terminal.




Position relationship between power cable terminals and AC cable terminals of the inverter.




### 5.11 Closing the Wiring Compartment

Step 1 Reinstall the protection plate and push the four plastic rivets into the holes at the chassis.



Step 2 Close the wiring compartment and tighten the four screws on its front cover with screwdriver T30.



### 5.12 DC Cable Connection



#### DANGER

Electric shock!

The PV array will generate lethal high voltage once exposed to sunlight.



#### CAUTION

Make sure the PV array is well insulated to ground before connecting it to the inverter.



#### NOTICE

There is a risk of inverter damage! The following requirements should be met.

Failure to do so will void guarantee and warranty claims.

- Make sure the maximum voltage of each string is always less than 1100 V.
- The inverter enters the standby state when the input voltage ranges between 1,000V and 1,100V. The inverter returns to the running state once the voltage returns to the MPPT operating voltage range, namely, 200 to 1,000V.
- Make sure the maximum short circuit current on the DC side is within the permissible range.

### 5.12.1 PV Input Configuration

The inverter is provided with multiple PV inputs: PV inputs 1~9; and each PV input is designed with an MPP tracker. Each PV input operates independently and has its own MPPT. In this way, string structures of each PV input may differ from each other, including PV module type, number of PV modules in each string, angle of tilt, and installation orientation. Each PV input area includes two DC inputs DC1 and DC2. For the best use of DC power, DC1 and DC2 should be the same in PV string structure, including the type, number, tilt, and orientation of the PV modules.

### 5.12.2 Connection Procedure


CSI Solar provides corresponding plug connectors in the scope of delivery for quick connection of PV inputs. DC cables should be connected to the inverter via PV connectors which are included in the scope of delivery.





#### **DANGER**

High voltage may be present in the inverter!

- Ensure all cables are voltage-free before performing electrical operations.
- Do not connect the AC circuit breaker before finishing electrical connection.
- Before wiring ensure all the DC switches to "OFF" position.




Step 1 Strip the insulation from each DC cable by 7mm.



Step 2 Assemble the cable ends with the crimping pliers


Step 3 Lead the cable through cable gland, and insert into the insulator until it snaps into place.

Gently pull the cable backward to ensure firm connection. Tighten the cable gland and the insulator (torque 2.5 N.m to 3 N.m).



Step 4 Check for polarity correctness.

The inverter will not function properly if any PV polarity is reversed.




### 5.12.3 Installing the PV Connectors.

step 1 Rotate all the DC switches to "OFF" position.

step 2 Check the cable connection of the PV string for polarity correctness and ensure that the open circuit voltage in any case does not exceed the inverter input limit of 1,100V.

step 3 Connect the PV connectors to corresponding terminals until there is an audible click.



 **NOTICE**

Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness.  
Arc or contactor over temperature may occur if the PV connectors are not firmly in place, and CSI Solar shall not be held liable for any damage caused.

step 4 Follow the foregoing steps to connect PV connectors of other PV strings.

step 5 Seal the unused PV terminals with the terminal caps.

### 5.12.4 Wiring Procedure

Refer to the wiring of terminal block described in chapter 5.9.3 Connection Procedure

## 6 Commissioning Inverter

### 6.1 Electrical Inspection

- 1) The inverter DC switch and external circuit breaker are disconnected
- 2) The inverter should be accessible for operation, maintenance and service.
- 3) Nothing is left on the top of the inverter.
- 4) The inverter is correctly connected to the external devices, and the cables are routed in a safe place or protected against mechanical damage.
- 5) The selection of the AC circuit breaker is in accordance with this manual and all applicable local standards.
- 6) All unused terminals at the bottom of the inverter are properly sealed.
- 7) Warning signs & labels are suitably affixed and durable.

### 6.2 Commissioning Procedure

If all of the items mentioned above meet the requirements, proceed as follows to start up the inverter for the first time.

Step 1 Rotate the DC switch of the inverter to "ON" position.

Step 2 Connect the AC switch (if applicable) between the inverter and the grid.

Step 3 Connect the DC switch (if applicable) between the inverter and the PV string.

Step 4 Set initial protection parameters via the CSI Cloud App. If the irradiation and grid conditions meet requirements, the inverter will normally operate.

Step 5 Observe the LED indicator to ensure that the inverter operates normally. (Refer to Tab. 2-2LED indicator description).

## 7 System Decommissioning

### 7.1 Disconnecting the Inverter

For maintenance or other service work, the inverter must be switched off.

Proceed as follows to disconnect the inverter from the AC and DC power sources.

Lethal voltages or damage to the inverter will follow if otherwise.

Step 1 Disconnect the external AC circuit breaker and secure it against reconnection.

Step 2 Rotate the DC switches to the "OFF" position for disconnecting all of the PV string inputs .

Step 3 Wait about 5 minutes until the capacitors inside the inverter completely discharge.

Step 4 Ensure that the DC cable is current-free via a current clamp.

Step 5 Insert a MC4 wrench into the notch and press the wrench with an appropriate force to remove the DC connector.

Step 6 Ensure that the AC wiring terminals are voltage-free via a multimeter, and remove the AC wires and communication wires.

Step 7 Install the MC4 waterproof plugs.

### 7.2 Dismantling the Inverter

Step 1 Refer to "5 Electrical Connection"for the inverter disconnection of all cables in reverse steps.

Step 2 Dismantle the inverter referring to "4 Mechanical Mounting" in reverse steps.

Step 3 If necessary, remove the wall-mounting bracket from the wall.

Step 4 If the inverter will be reinstalled in the future, please refer to "3.4 Inverter Storage" for a proper conservation.

### 7.3 Disposal of the Inverter

Users take the responsibility for the disposal of the inverter.



#### NOTICE

Some parts and devices of the inverter, such as the capacitors, may cause environmental pollution.

Do not dispose of the product together with household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.

## 8 Daily Maintenance

 DANGER	Risk of inverter damage or personal injury due to incorrect service! Always keep in mind that the inverter is powered by dual sources: PV array and utility grid. Before any service work, observe the following procedure. 1) Disconnect the inverter from the utility grid side first and then PV array; 2) Wait at least 5 minutes after shut down the inverter, for inner capacitors to discharge completely; 3) Verify that no voltage and current existing with appropriate testing devices.
 NOTICE	Risk of inverter damage if it is improperly serviced. Use accessories and spare parts approved by the inverter manufacturer only. Never modify the inverter or other components of the inverter. The loss of any or all warranty rights may follow if otherwise.
 NOTICE	Any malfunction that may impair the inverter safety operation must be repaired immediately before the inverter is restarted. Inverter contains no customer serviceable parts inside. Please contact local authorized personnel if any service work is required.
 Information	Servicing of the device in accordance with the manual should never be undertaken in the absence of proper tools, test equipment or the more recent revision of the manual with has been clearly and thoroughly understood.

Items	Methods	Period
System clean	Check the temperature and dust of the inverter. Clean the inverter enclosure. Check the humidity and dust of the environment. Meanwhile check whether the filter function of the air inlet is ok.	Six months to a year (it depends on the dust contents in air.)
Fans	Check whether there is fan warning using App. Check whether there is any abnormal noise when the fan is turning. Clean or replace the fans if necessary (see the following section).	Once a year
Cable entry	Check whether the cable entry is insufficiently sealed or the gap is excessively large, and reseal the entry when necessary.	Once a year
Electrical Connection	Check whether all cable are firmly in place. Check whether a cable is damaged, especially the part contacting the metal enclosure.	Six months to a year.

### 1) Cleaning Air Inlet and Outlet

A huge amount of heat is generated in the process of running the inverter. The inverter adopts a controlled forced-air cooling method.

In order to maintain good ventilation, please check to make sure the air inlet and outlet are not blocked.

Clean the air inlet and outlet with soft brush or vacuum cleaner if necessary.

### 2) Internal Fan Maintenance


Fans inside the inverter are used to cool the inverter during operation. If the fans do not operate normally, the inverter may not be cooled down and inverter efficiency may decrease. Therefore, it is necessary to clean the dirty fans and replace the broken fans in time.

The operation procedure is as follows:

Step 1 Stop the inverter.


Step 2 Loosen four screws on the front cover of the wiring compartment with screwdriver T30.

Step 3 Open the wiring compartment.




Step 4 Cut off the cable ties that securing the fan connectors, press the hump of the latch hook, then unplug the cable connection joint outwards.

Step 4 Loosen screws from the fan module, and pull out the fan module




Step 5 Insert the new fan module into the track and secure the screws.

Insert the fan connector and the internal cable connector in position (note the correspondence), and secure the fan connector by cable ties.



Close the wiring compartment.



**DANGER**

Stop the inverter and disconnect it from all power supplies before maintenance.


Lethal voltage still exists in the inverter. Please wait for at least 5 minutes and then perform maintenance work.

Only qualified electricians can maintain the fans.


### 3) External Fan Maintenance

Loosen the screws of the fan module cover, and remove it. (Note, Cover plate is on the left side of the inverter.)


Press the hump of the latch hook, then unplug the cable connection joint outwards.




Loosen screws from the fan module, and pull out the fan module



Insert the fan connector into the track, and secure the fan connector by screws.



Insert the fan connector and the internal cable connector in position (note the correspondence), and secure the fan connector by cable ties.



## 9 Troubleshooting

When the inverter does not operate normally, we recommend the following actions for quick troubleshooting. Please review the error list table carefully.

### 9.1 Warning

The different LED colors and flashing status identify the current operation statuses of the inverter. If the red color is always on, it indicates the inverter fault. Usually the warnings can be cleared through an orderly shutdown / reset or a self-corrective action performed by the inverter.

### 9.2 Errors

Error codes identify a possible equipment fault, or incorrect setting/ configuration. Any and all attempts to correct or clear a fault must be performed by qualified personnel. Typically, the Errors code can be cleared once the cause or fault is removed.

However, some of the (E) codes may cannot be cleared, in this case please contact the dealer or CSI Solar Co., Ltd. to replace a new one.

Errors as indicated in the table below:

Error Code	Description	Trouble shooting
A001	External Fan Warning	1. Check whether the fans operate normally and are blocked by sundries. If they are blocked, clear the sundries. 2. If a fan does not operate normally, stop and disconnect the inverter to replace the fan.
A002	Internal Fan Warning	
A003	Device anomaly	Wait for the inverter to return to normal. Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter. If the fault still exists, contact CSI Solar.
A004	Input Spd Warning	Check the SPD, and replace it if necessary
A005	Device anomaly	Wait for the inverter to return to normal. Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter. If the fault still exists, contact CSI Solar.
A006	Output Spd Warning	Check the SPD, and replace it if necessary
F001~F005	Device anomaly	Wait for the inverter to return to normal. Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter. If the fault still exists, contact CSI Solar.
F006	Grid Line Vol Overvolt Err	Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly: 1. Measure the actual grid voltage, and contact the local electric power company for solutions if the grid voltage is higher than the set value. 2. Check whether the protection parameters are appropriately set via the App or the LCD. 3. Check whether the cross-sectional area of the AC cable meets the requirement. 4. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.
F007	Grid Phase Vol Overvolt Err	

F008	Device anomaly	<p>Wait for the inverter to return to normal.</p> <p>Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter.</p> <p>If the fault still exists, contact CSI Solar.</p>
F009	Grid Freq High Err	<p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Measure the actual grid frequency, and contact the local electric power company for solutions if the grid parameter exceeds the set value.</li> </ol>
F010	Grid Freq Low Err	<ol style="list-style-type: none"> <li>2. Check whether the protection parameters are appropriately set via the App or the LCD.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F011	No Utility Err	<p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Check whether the grid supplies power reliably.</li> <li>2. Check whether the AC cable is firmly in place.</li> <li>3. Check whether the AC cable is connected to the correct terminal (whether the live wire and the N wire are correctly in place).</li> <li>4. Check whether the AC circuit breaker is connected.</li> <li>5. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F012	Device anomaly	<p>Wait for the inverter to return to normal.</p> <p>Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter.</p> <p>If the fault still exists, contact CSI Solar.</p>
F013	Over Temp Err	<ol style="list-style-type: none"> <li>1. Check whether the inverter is directly exposed to sunlight. If so, take some shading measures.</li> <li>2. Check and clean the air ducts.</li> <li>3. Check whether there is A001 or A002 (fan anomaly) alarm via the App or the LCD. If so, replace the fans.</li> </ol>
F014~F017	Device anomaly	<p>Wait for the inverter to return to normal.</p> <p>Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter.</p> <p>If the fault still exists, contact CSI Solar.</p>
F018	Iso Low Err	<p>Wait for the inverter to return to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Check whether the ISO resistance protection value is excessively high via the App or the LCD, and ensure that it complies with the local regulations.</li> <li>2. Check the resistance to ground of the string and DC cable. Take correction measures in case of short circuit or damaged insulation layer.</li> <li>3. If the cable is normal and the fault occurs on rainy days, check it again when the weather turns fine.</li> <li>4. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>

F019	GFCI High Err	<ol style="list-style-type: none"> <li>1. The fault can be caused by poor sunlight or damp environment, and the inverter will be reconnected to the grid after the environment is improved.</li> <li>2. If the environment is normal, check whether the AC and DC cables are well insulated.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F020	Freq Detect Err	<p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Measure the actual grid frequency, and contact the local electric power company for solutions if the grid parameter exceeds the set value;</li> <li>2.4. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F021~F022	Device anomaly	<p>Wait for the inverter to return to normal.</p> <p>Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter.</p> <p>If the fault still exists, contact CSI Solar.</p>
F023	Grid Volt unBalance Err	<p>Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:</p> <ol style="list-style-type: none"> <li>1. Measure the actual grid voltage. If grid phase voltages differ greatly, contact the power company for solutions.</li> <li>2. If the voltage difference between the three phases is within the permissible range of the local power company, modify the grid voltage imbalance parameter through the App or LCD screen.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F024	Inv Curr unBalance Err	<p>Wait for the inverter to return to normal.</p> <p>Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter.</p> <p>If the fault still exists, contact CSI Solar.</p>
F025	Hardware Power Module Err	
F026	Hardware Bus Overvolt Err	
F027	GFCI CT Err	
F030	PV2 Rev Connect Err	<ol style="list-style-type: none"> <li>1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the solar radiation is low and the string current drops below 0.5A.</li> <li>2. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F031	Boost 3/4 Curr High Err	<ol style="list-style-type: none"> <li>1. Check if the xth PV string needs to be connected. If not, ignore the alarm; and If so, check the connection status and make sure it is connected reliably.</li> <li>2. Check if the xth DC fuse is damaged. If so, replace the fuse.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F032	PV2 Volt High Err	
F033	Device anomaly	<p>Wait for the inverter to return to normal.</p> <p>Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter.</p> <p>If the fault still exists, contact CSI Solar.</p>

F034	PV1 Rev Connect Err	<ol style="list-style-type: none"> <li>1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the solar radiation is low and the string current drops below 0.5A.</li> <li>2. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F035	PV1 Volt High Err	<ol style="list-style-type: none"> <li>1. Check if the xth PV string needs to be connected. If not, ignore the alarm; and If so, check the connection status and make sure it is connected reliably.</li> <li>2. Check if the xth DC fuse is damaged. If so, replace the fuse.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F036	PV3 Rev Connect Err	<ol style="list-style-type: none"> <li>1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the solar radiation is low and the string current drops below 0.5A.</li> <li>2. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F037	PV3 Volt High Err	<ol style="list-style-type: none"> <li>1. Check if the xth PV string needs to be connected. If not, ignore the alarm; and If so, check the connection status and make sure it is connected reliably.</li> <li>2. Check if the xth DC fuse is damaged. If so, replace the fuse.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F038~F042	Device anomaly	<p>Wait for the inverter to return to normal. Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter. If the fault still exists, contact CSI Solar.</p>
F043	Arcing Err	<ol style="list-style-type: none"> <li>1. Disconnect the DC inputs and check whether DC cables are damaged, whether the wiring terminals or fuses are loose or in poor contact, and whether component parts are burnt. If so, take corresponding corrective measures.</li> <li>2. After taking corresponding measures in step 1, reconnect the DC inputs. Remove the arc fault through the App or LCD screen so that the inverter will recover to be normal.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact</li> </ol>
F044	GFCI Steady Err	<ol style="list-style-type: none"> <li>1. The fault can be caused by poor sunlight or damp environment, and the inverter will be reconnected to the grid after the environment is improved.</li> <li>2. If the environment is normal, check whether the AC and DC cables are well insulated.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F047	Boost5/6 Curr High Err	<ol style="list-style-type: none"> <li>1. Check if the xth PV string needs to be connected. If not, ignore the alarm; and If so, check the connection status and make sure it is connected reliably.</li> <li>2. Check if the xth DC fuse is damaged. If so, replace the fuse.</li> <li>3. If the fault is not caused by the foregoing reasons and still exists, contact CSI Solar.</li> </ol>
F048~F062	Device anomaly	<p>Wait for the inverter to return to normal. Disconnect the AC and DC switches, and reconnect the AC and DC switches 15 minutes later to restart the inverter. If the fault still exists, contact CSI Solar.</p>

## ANNEX: Specification

Model	CSI-75K-T40001-E	CSI-80K-T40001-E	CSI-100K-T4001A-E	CSI-100K-T4001B-E	CSI-110K-T40001-E
<b>INPUT(DC)</b>					
Max. DC Input Voltage (V)	1100 V <sub>DC</sub>				
Startup DC Input Voltage (V)	195 V <sub>DC</sub>				
MPPT Voltage Range (V)	200-1000 V <sub>DC</sub>				
Rated Input Voltage (V)	600 V <sub>DC</sub>				
Max. Input Current (Imp)	6 x 40 A	6 x 40 A	6 x 40 A	9 x 30 A	9 x 30 A
Max. Short-Circuit Current (ISC)	6 x 50 A	6 x 50 A	6 x 50 A	9 x 40 A	9 x 40 A
Number of MPP Trackers	6	6	6	9	9
Number of DC Inputs	12	12	12	18	18
DC Switch	Integrated				
<b>AC OUTPUT</b>					
Rated Output Power	75 kW	80 kW	100 kW	100 kW	110 kW
Max. AC Output Power (Apparent)	75 kVA	80 kVA	100 kVA	100 kVA	110 kVA
Rated Output Voltage	380 / 400 V <sub>AC</sub>				
Grid Connection Type	3 L / N / PE, or 3L / PE				
Max. Output Current	114 A	121.6 A	152 A	152 A	167 A
Rated Output Frequency	50 / 60 Hz				
Power Factor	> 0.99 (0.8 leading ... 0.8 lagging)				
Total Harmonic Distortion (THDi)	< 3%				
Zero Export Solution	Supported				
<b>SYSTEM</b>					
Max. Efficiency	98.7 %				
EU Efficiency	98.3 %				
MPPT Efficiency	99.9 %				
Night Consumption	< 10 W				
Anti-PID Module	Integrated				
<b>ENVIRONMENT</b>					
DC / AC SPD	DC SPD Type II / AC SPD Type II (Type I Optional)				
Protection Degree	IP66, C5				
Cooling	Intelligent Cooling				
Operating Temperature Range	-30 °C to +60 °C				
Operating Humidity	0 - 100 % Non-condensing				
Operating Altitude	4000 m (> 3000 m derating)				
<b>DISPLAY AND COMMUNICATION</b>					
Display	LED & APP				
Communication	RS485 / WiFi / Ethernet				
<b>MECHANICAL DATA</b>					
Dimensions (W / H / D)	1050 x 600 x 355 mm				
Weight	95 kg				
DC Inputs Type	MC4				
AC Outputs Type	OT Terminals (Support the AC cables Max. 240mm <sup>2</sup> )				
<b>SAFETY</b>					
Safety and EMC Standard					
Grid Standard					
Grid Connection Standard					

## China – Global Headquarters

CSI Solar Co., Ltd.

199 Lushan Road, SND, Suzhou, Jiangsu, China, 215129

Sales Inquiries Email: [info@csisolar.com](mailto:info@csisolar.com)